




1 SEE DETAIL 1/S330 FOR REQUIRED DEMOLITION PRIOR
TO EXTENDING EFFLUENT WEIR TROUGH WALL.



DETAIL	1
$1^s = 1^i - 0^s$	S330

PLOT DATE 07/08/03 12:07pm FILE= H:\30788\30788A\STRU\g.330 by DZIMPEL XREFs=30788g\mlsc\30788tb.330\feb2-pt.330\feb2-s01