





NOTES:

- DO NOT INSTALL INSULATION
 ON INLET PIPING UNTIL ALL
 PAINTING IN THE INTERIOR DRY
 AREA HAS BEEN APPROVED BY
 THE PROJECT ENGINEER IN CHARGE
- INSULATION SHALL BE 2" THICK TRYMER 2000 RIGID FOAM INSULATION W/ ALL-SERVICE JACKET & SELF-SEALING JOINTS.
- 3" WHITE DUCT TAPE SHALL BE APPLIED AT ALL HORIZONTAL JACKET SEAMS. DUCT TAPE SHALL BE COVERED WITH ASJ TAPE SUPPLIED WITH THE JACKET.
- 4. APPLY 3/4" FILAMENT TAPE 9" O.C.

AS BUILT

